



GreenCleanPRO is an effective, biodegradable chemistry formulated to kill and treat for fungus, molds, mildew, bacteria and algae. The user-friendly product granules are activated when mixed with water or by post broadcast wetting of the treated surfaces. Once the product has made contact with a wide range of organisms and organic material it converts to water, oxygen and carbon dioxide.

DRY GRANULAR TREATMENT

GreenCleanPRO can be applied as a granular product to dry, damp or wet surfaces at a wide range rates to kill and treat fungus, molds, mildew, bacteria and algae. When applying as a granular product, the selected spreader should be capable of providing even coverage at all settings. The recommended rate/area are as follows:

INFESTATION GROWTH COVERAGE	PRODUCT APPLICATION RATE (lb)	COVERAGE (SQ. FT.)	CONTACT TIME (MINUTES)	WATER VOLUME*
LIGHT	0.5	800-1000	10-60	1/10 INCH
LIGHT/MODERATE	0.75	800-1000	10-60	1/10 INCH
MODERATE	1.0	800-1000	10-60	1/10 INCH
MODERATE/HEAVY	1.5	800-1000	10-60	1/10 INCH
HEAVY	2.0	800-1000	10-60	1/10 INCH

* Amount of water recommended to ensure proper wetting of product on treated surfaces.

DIRECTIONS:

1. Dampen or wet surface to be treated if necessary.
2. Measure product according to mold, algae or slime coverage density. Place product in spreader. Test coverage on area to ensure spreader coverage is even.
3. Broadcast product on surfaces, then wet according to volume shown on chart.
4. After sufficient contact time, mechanically or use pressure washer to remove debris or dead matter from treated surface.
5. Repeat treatment if and as necessary.

LIQUID APPLICATIONS

GreenCleanPRO can be easily dissolved in water (50-70° F). Once product has been dissolved in water, product can be applied as a spray, mist or foam. Complete surface coverage is required to achieve best results. Additional surfactants may be added to increase wetting properties. Refer to chart below for appropriate rates.

SPRAY, MIST OR FOAM APPLICATIONS:

INFESTATION GROWTH COVERAGE	PRODUCT APPLICATION RATE/GAL	COVERAGE (SQ. FT.)	CONTACT TIME (MINUTES)	FOAM/SURFACTANT CONCENTRAT (fl. oz./gal)*
LIGHT	1/8 cup	800-1000	10-60	1
LIGHT/MODERATE	1/4 cup	800-1000	10-60	1
MODERATE	1/3 cup	800-1000	10-60	1
MODERATE/HEAVY	1/2 cup	800-1000	10-60	1
HEAVY	3/4 cup	800-1000	10-60	1

**Additional surfactant/foaming agent may be added to enhance contact time on ceilings and vertical walls.*

DIRECTIONS:

1. Measure water volume of vessel or tank to be used as source for spraying/foaming device.
2. Calculate amount of product required by the degree of infestation.
3. Add measured amount of GreenCleanPRO and agitate by shaking or swirling until it appears that most or all granules have dissolved, then add surfactants or foaming as desired.
4. Spray, mist or foam areas with prepared solution. Allow foam to remain on surfaces for time as shown in chart or until dry.
5. Mechanically or with a pressure washer, remove dead matter and debris from surfaces.
6. Re-apply or treat if and as necessary for desired results.

**For more information, contact us at: 1.888.273.3088 (toll-free)
Or visit us online at: www.biosafesystems.com**